



klavier Bronze met voorbereiding Ekey

FTBR24KE

Voor Ekey integratie met Bronze keypad FT24KBR



FTBR24KE


Het betreft de buitenpost incl. de benodigde voeding maar excl. de benodigde interfaces Ekey of Ekey systemen zoals de ekey Home/multi of Net.

Deze dient u separaat te bestellen, evenals de integratie met onze Wizard Elite wiegand of standalone uitvoering.

Verder dient u rekening te houden dat dit klavier alleen ingebouwd kan worden.

Te bestellen:

FT25KBIS voor inbouw



Hierbij treft u de mogelijkheden en bestelnummers aan voor een werkend systeem:

Klavier Stand alone met Ekey Home

Bestelnummers: FTBR24KE / FT25KINT / EKEY / FTEKEYHOME / FTEKEYPS-voeding

Klavier Standalone met Ekey Multi

Bestelnummers: FTBR24KE / FT25KINT / EKEY / FTEKEYMULTI / FTEKEYPS-voeding

Klavier standalone met ekey Net

Bestelnummers: FTBR24KE / FT25KINT / EKEY / FTEKEYMULTI / FTEKEYPS-voeding / FTEKEYNET

Klavier wiegand aangesloten op Elite met Ekey Home

Bestelnummers: FT24BRKE / EKEY/ FTEKEYHOME / FTEKEYPS-voeding

Klavier wiegand aangesloten op Elite met Ekey Multi

Bestelnummers: FTBR24KE / EKEY / FTEKEYMULTI / FTEKEYPS-voeding

Klavier wiegand aangesloten op Elite met Ekey Net

Bestelnummers: FTBR24KE / EKEY / FTEKEYMULTI / FTEKEYPS-voeding / FTEKEYNET



Ekey offers 3 systems:

1. Home:

- Only 1 reader! With different fingers you can open up to 2 doors with that 1 reader.
- No pc software
- No registration
- No time tables / special rights/
- Integration with third party wiegand access control is possible with extra module. In this way special rights per user and registration are possible
- Basic system for villa

2. Multi

- Same as Home but up to 4 readers. Each reader can open 1 door

3. Net

- If more than 4 readers are needed
- Or when registration of the users and special rights are needed done by PC software
- But those last ones are also possible if an external wiegand access control system is installed. When an external Wiegand access control system is installed only use net if more than 4 readers are needed.

Please inform us for each installation what kind of system you want and we will make sure the right parts are in the box.